

Phosphate

| Name of the test | Phosphate |
|-------------------|--|
| Test Range (ppm) | 0 - 1.8 |
| Unit | mg/L |
| Correlation | 0.85 |
| Method | Colorimetric |
| Calibration point | 0 ррт |
| Time taken | 10 minutes |
| Storage | Keep in a dry and cool place and away from sunlight. |
| Safety | Avoid contact with skin and use gloves to perform a test. |
| Shelf Life | 6 months from the date of manufacturing. |
| Limitations | Arsenates react with the molybdate reagent to produce a blue colour similar to that formed with phosphate. Concentrations as low as 0.1 mg/L interfere with the test results. Hexavalent chromium and NO_2 interfere to give results at about 3% lower at concentrations of 1 mg/L and 10 to 15 % lower at 10 mg/L. Sulphide (Na_2S) and silicate do not interfere at concentrations of 1.0 and 10 mg/L. |

^{*}Tests to be performed in a well lit ambience with natural light

^{*}These tests do not work with turbid or coloured water samples