

SCAN TO DOWNLOAD THE FORM



Fig 1: Aligning the cards (Colorimetric tests)




Fig 2: Focusing on the chamber (Turbidity and Hazen Units test)





Fig 3: Folding the filter paper into the funnel (Filtration)



3.1.1 : Table of Variables (Titration Tests)

Parameter	Volume of sample (in ml)	Reagent	Mixing procedure	Color change to look for while adding titration solution
<b>Total Hardness</b>	10	One bottle of reagent A and one bottle of reagent B and one bottle of titrant	Add half spoon of reagent A and 10 drops of reagent B and mix the contents well.  Titrate with titrant bottle drop by drop	<b>Red to Blue</b>

<b>Total Alkalinity</b>	10	One bottle of reagent A and one bottle titrant	<p>Add 2 drops of reagent A and mix well.</p> <p>-If pink color appears, it indicates presence of p alkalinity. Add titrant drop by drop until the pink color disappears. Note the drops in titration 1 drops. If pink color doesn't appear note '0' in titration 1 drops.</p> <p>- To this solution add half spoon reagent B and solution turns green. Titrate drop by drop with titrant until green turns reddish violet and note the drops in titration 2 drops.</p>	<p><b>Colorless to Pink</b></p> <p><b>Colorless to Green</b></p> <p><b>Green to Reddish Blue</b></p>
-------------------------	----	--	---	--

### 3.1.2 : Table of Variables (Colorimetric Tests)

The sample volume, reagent volume and wait time is the same when calibrating and/or testing

Parameter	Volume of sample (in ml)	Reagent	Mixing procedure	Range limits (in mg/l)
<b>Fluoride</b>	5	One dropper bottle of Fluoride Reagent	<p>Add <b>5 drops</b> of Fluoride Reagent to the sample solution</p> <p>Shake gently 2-3 times</p>	0 - 2

<b>Nitrate</b>	10	One strip of tablets each of Nitrate Reagent A and B	<p>Add <b>1 tablet of Nitrate Reagent A</b> and <b>1 tablet of Nitrate Reagent B</b> to the sample solution</p> <p>Shake well until tablets have dissolved</p>	0 - 75
<b>Free Chlorine</b>	5	One dropper bottle of chlorine reagent	<p>Add 5 drops of Free chlorine reagent to the sample solution</p> <p>Shake well</p>	0 - 3
<b>Iron</b>	5	One 30 ml dropper bottle Iron A reagent and One 60 ml dropper bottle for Iron B reagent	<p>Add 1 drop of Iron A reagent and Add 5 drops of Iron B reagent to sample solution.</p> <p>Shake gently 2-3 times</p>	0-1.5
<b>pH</b>	5	One dropper bottle of Universal pH indicator	<p>Add <b>1 drop</b> of Universal pH indicator to the sample solution</p> <p>Shake gently 2-3 times</p>	4 - 10

### 3.1.3: Table of Variables (Hazen Units and Turbidity Tests)

The sample volume, reagent volume and wait time is the same when calibrating and/or testing

Parameter	Volume of sample (in ml)	Mixing procedure	Range limits (in mg/l)
Hazen Units	5-10	Take 15-20 ml of the sample or calibration solution till it reaches the brim of the testing chamber	0 - 30
Turbidity	5-10	Take 15-20 ml of the sample or calibration solution till it reaches the brim of the testing chamber	0 - 30